



Yellow Flame Butane Lighter Inserts
English USA - en

Model #28420

© Zippo Manufacturing Company 2021.



To re-flint your Zippo Yellow Butane Lighter:
Insert Remove screw (6) and attached spring at the bottom of the insert. Be sure old flint is removed from tube. Place new flint in tube and replace spring, screw lightly. Be sure screw is turned as far as it will go, if wheel binds after new flint is inserted, turn wheel backwards a few times.



FILLED / UNFILLED TORCH INSERT WARNINGS:
WARNING: KEEP LIGHTER AND THEIR FUELS OUT OF REACH OF CHILDREN.
Ignite lighter away from face and clothing. Be sure flame is out after use. If filled, contains flammable gas under pressure. If unfilled, when filled, will contain flammable gas under pressure. Never expose to heat above 50°C (122°F) or to prolonged sunlight. Never puncture or put in fire. Do not keep it for more than 30 seconds. Do not refill over containers such as sinks or near a flame. Butane tends to settle and collect in the lowest point.



If you have any problems with the operation of your Product, **DO NOT return it to the retail store**. Instead, consumers should contact their local distributor listed on zippo.com.

ΔΩΣΗ: Read all safety warnings and instructions. Failure to follow the warnings and instructions may result in Product damage and/or serious injury. Extra care should be taken to prevent burn, injury, or fire. See these instructions for future reference.

GENERAL SAFETY WARNINGS AND INSTRUCTIONS:

- Keep flammables and their fuels out of reach of children.
- Do not light lighter from face and clothing.
- Be sure flame is out after use.
- When filled, will contain flammable gas under pressure.
- Use butane fuel only.
- DO NOT refill over containers such as sinks or near a flame. Butane tends to settle and collect in the lowest point.
- Fill or refill in a well-ventilated area.
- Hold insert or lighter away from face.
- For safe refilling: ensure proper mating between refill can nozzle and lighter filling valve.
- Wait at least 2 minutes after refilling before using the insert.
- DO NOT keep it for more than 30 seconds.
- Never expose to heat above 50°C (122°F) or to prolonged sunlight.
- Never puncture or put in fire.
- Do not point lighter towards face.
- This insert is only designed to work with regular-sized propane.
- Zippo Windproof® Lighter models including: Regular, Vintage, Armor®, and 1941 Replica.
- DOES NOT work with Slim or 1935 Replica models.
- DO NOT attempt to disassemble the Product for cleaning or modify it in any manner. This will void the warranty.
- Always grasp lighter case (edges with fingers) and thumb when inserting or removing butane insert. Grasping face of lighter may cause difficulty.
- Follow all instructions and warnings provided by manufacturer of any other item when using this product.

DISCLAIMER:
ZIPO WILL NOT BE RESPONSIBLE OR LIABLE FOR ANY DAMAGES YOU OR ANY THIRD PARTY MAY SUFFER AS A RESULT OF USE OR MISUSE OF THIS PRODUCT.

Yellow Flame Butane Lighter Inserts

1. Flint wheel
2. Ignition button
3. Flame
4. Case
5. Butane Filling Valve
6. Flint screw

Butane Filling Instructions:
Fill or refill in a well-ventilated area.



OPERATING INSTRUCTIONS:
Install the Insert into your Zippo Lighter Case.

1. Turn wheel
2. Ignition button
3. Flame
4. Case
5. Butane Filling Valve
6. Flint screw

Ignition:
Strike the Flint Wheel in a downward motion then press the Ignition Button with your thumb and hold to ignite flame.



Butane Filling Instructions:
Fill or refill in a well-ventilated area.



ar

خرطوشة واغلاع البيوتان بالبوب الأصفر

Model: 28420

تحذيرات السلامة المطلوبة / المقررة

تحذيرات السلامة المطلوبة / المقررة