



If you have any problems with the operation of your Product, DO NOT return it to the retail store. Instead, consumers in the U.S. should contact Zippo Consumer Relations at 888-442-9323 or visit zippo.com.

Pipe Lighter Insert

English USA - en

UNFILLED INSERTS WARNINGS:**WARNING: KEEP OUT OF REACH OF CHILDREN.**

Ignite lighter away from face and clothing. When filled, will contain flammable fluid. Never expose to heat above 122° F (50°C) or prolonged sunlight. Never puncture or put in fire. Be sure flame is out after use. This insert of lighter does not self-extinguish – close cover to put out. Fire is a skin irritant, do not overheat.

THIS LIGHTER IS NOT CHILD RESISTANT.**To fill your Zippo insert or lighter**

- Use Zippo lighter fuel for best performance
- Fill slowly, never overfill. Let fuel pool to reveal the packing material in the fuel chamber (1). Saturate the packing with Zippo lighter fuel. Stop filling when fuel reaches top of packing. If overfilled it can leak fuel. Fuel is a skin irritant.
- Pipe lighter and hands dry before igniting. Pipe insert or lighter case (2) is overfilled if water or pocket or next to heat or sun, wash the affected area. A filtration persists on wipers, see doctor.
- Be sure fuel is closed and there is no spilled fuel in vicinity before igniting. This is flammable fluid.

To re-light your Zippo insert or lighter

- Remove screw (3) and attached spring (4) end of fuel chamber. Be sure oil film is removed from tube. Pipe new film in tube and replace spring, screw lightly. Be sure screw is turned as far as it will go; if not, cover will not close properly. If fuel film ends after first is inserted, turn wheel backwords a few times.

Wick Maintenance

Whenwick becomes black from carbon, pull it up with tweezers until clean wick appears (approx. 1 cm), then trim the end making it even with the chimney height.

Perform this maintenance 1 or 2 times a year. It will be necessary to replace the wick after it has been trimmed more than 2 or 3 times.

For more information visit the website listed.

UK**УВАГА! ЗБЕРІГАЙТЕ ЗАПАЛЬНИЧУ ВІД МІСЦІ, НЕДОСТУПНОМУ ДЛЯ ДІТЕЙ.**

Запалювачі містять легковзрізну рідину. Не лідажуйте запалювачем відповідно до інструкції. Слідкість запалювача може викликати погану реакцію та поранення.

Слідкість запал