


Outdoor Utility Lighter (OUL®)



The rugged design of the Zippo Outdoor Utility Lighter (OUL®) features a patented child-resistant safety lock button (A) which, when depressed, releases and allows the ignition button (B) to engage. Note that the Outdoor Utility Lighter is pre-filled with butane fuel.

To operate:

1. Depress and hold safety lock button (A)
2. Depress and hold the ignition button (B) to ignite and maintain flame
3. Release the ignition switch (B) to extinguish flame and stop fuel flow

Caution: Hold the device upright until the flame is fully extinguished.

Do not refill near flame, heat source or sparks. Use only in well ventilated area. Keep lighter and fuel out of reach of children.

To adjust flame:

Turn regulator (C) to + (higher) or to - (lower).



To refill with butane fuel:

- 1) Use only a premium grade butane fuel to refill. Use of other than Zippo Premium Butane Fuel may result in damage to the filling valve and could cause clogging.
- 2) Always refill in the position shown. Place butane fuel nozzle into filling valve (D) and depress with firm, even pressure. Hold for several seconds. Repeat if necessary. Please ensure proper mating between the refill container and fuel reservoir of the lighter during refilling to avoid leakage of fuel.
- 3) Wait at least two minutes after refueling before using.



Filling valve



Zippo Manufacturing Company
33 Barbour Street
Bradford, PA 16701

Complies with ASTM F2201-10
and is Child Resistant
Printed in China

121399-F

Zippo Premium Butane Fuel is recommended for your Zippo Flexible Neck Utility Lighter and other refillable butane products.



Additional Information

- Like all butane lighters, this product will not perform well at an altitude of over 5,000 feet (1,500 meters).
- If you have any problems with the operation of your Outdoor Utility Lighter, do not return it to the store. Instead, contact Zippo for operating tips and repair instructions. For repairs, special shipping procedures apply (due to government regulations). Shipping information can be found on zippo.com or by contacting Zippo Consumer Relations at 814-368-2700. A \$5.00 shipping and handling fee applies to repairs of the Outdoor Utility Lighter.

To obtain service under this warranty, refer to repair instructions at Zippo.com or U.S. consumers should contact Consumer Relations at 814-368-2700.

Consumers outside the U.S. should contact your local distributor. **Under no circumstances should you mail a Outdoor Utility Lighter to Zippo.** Please follow the advice of the local distributor in your country; see listing.



Warranty

Any Zippo Outdoor Utility Lighter returned to our factory for warranty repair within three years of purchase will be repaired free of charge or replaced, at our discretion. There is a \$5.00 shipping and handling fee. Damage to the Outdoor Utility Lighter resulting from abuse or misuse is not covered by our warranty. The finish is also not warranted.

This warranty gives you specific legal rights and you may also have other rights which vary state to state. Other Zippo products carry their own specific warranties.